

PEEL & STICK INSTALLATION PROCEDURE

Peel and Stick is a revolutionary way to install stair nosings. It is specifically designed to be fitter friendly and speed up the installation of stair nosings without losing the strength or durability of traditional fixing methods.

1. Subfloors must be sound, smooth, clean, dry, free from grease, dust or any contamination that will affect adhesion.
2. Ensure all steps are flat and level (use a repair mortar to make good any irregularities)
3. Remove any debris and make sure the steps are dry, clean and dust free.
4. Absorbent surfaces must be primed using Morleys Universal Primer JM1000
5. Ensure the primer is fully dry before applying the Peel & Stick Stair Nosing
6. Ensure the temperature does not fall below -5°C or exceed 45°C
7. All nosings are supplied pre-cut to size, with the step number and size written on the back. *Note -: Number one nosing is always at the top.
8. Place number one nosing on the top step and check it fits correctly. Place a pencil on the back edge of the nosing and draw a pencil line on the tread.
9. Remove the protective paper from the back of the nosing.
10. Place the nosing at an angle of 45° on to the step, lining up the back edge of the nosing to the pencil line on the tread, then slowly lower the nosing on to the tread. It is important to line up the nosing correctly as once the adhesive tape makes contact with the tread the bond will become permanent.
11. Using a hand roller, apply pressure to the entire length of the nosing.
12. Repeat the procedure for the remaining steps.

